

High Gold Content Bonding Alloy, Type 4

PLATINOR® AM 3

acc. to DIN EN ISO 9693
acc. to DIN EN ISO 22674

Item no. 7316 3 001

Delivery form Casting plates

Indication Classic ceramic
inlays, onlays, crowns
larger span bridges
milling-, conus- and telescope technique

QM-System certified
according to DIN EN ISO 13485
for medical products



Alloy: Au 82 Pt 8 Pd 7

Type	Colour	Density g/cm ³	Composition content in % (m/m)									
			Au + Pt metals	Au	Pt	Pd	Ir	Ag	Cu	Sn	In	Fe
4	white	17.3	95.3	77.0	9.2	9.0	0.1	1.5	0.4	1.0	1.6	0.2

The alloy is free of Ni, Co, Cr, Be, Cd.

Technical data

Vickers hardness HV 5/30			0.2 % proof stress MPa		Elongation %		Modulus of elasticity MPa	Average linear CTE µm/m · K		Melting range °C	Preheating temp. °C	Casting temp. °C	Annealing °C min	Hardening °C min
g	n	a	n	a	n	a		25-500 °C	25-600 °C					
170	180	210	440	565	14	10	106.000	14.1	14.3	1130-1255	850	1390	-- --	600 15

g = after casting, n = after firing, a = hardened

Solders

Application	Solder	Working temp. °C	Composition content in %								Colour
			Au	Pt	Pd	Ir	Ag	Cu	Zn		
Primary solder/ before firing Secondary solder/ after firing	PLATINOR® AM-Lot	1070	80.0	-	7.5	-	8.0	3.9	0.6	yellow	
	PLATINOR® -Lot 1	810	70.0	0.9	1.0	0.1	11.0	7.0	10.0	yellow	
	PLATINOR® -Lot 2	760	70.0	0.9	0.5	0.1	12.0	4.5	12.0	yellow	

Instruction for use

Instruction for use PLATINOR® AM 3

1. Modelling

Create an anatomically reduced wax model, considering the planned veneering. Sharp edges are to be avoided, soft level crossings are to be striven at.

Due to stability reasons, care has to be taken at bridge frames to achieve solid modulation of the connections and in the case of larger spans to create palatal and interdental strength of the connecting parts. Wall thickness of the modelled (waxed) single crowns at least 0.4 (0.3) mm, bridge pillar crowns at least 0.5 (0.4) mm.

2. Spruing System

Single crown:

Direct spruing with casting channel at least Ø 3.5 mm

From 2 single crowns on and bridges:

Running bars or rings with

object spruing 3.0 x Ø 3.0 mm

running bars/rings Ø 4.0 – Ø 5.0 mm

casting channels Ø 3.5 – Ø 4.0 mm

3. Position of the Wax Model in the Investment Mould

Distance from the mould wall: The units should have at least 5-10 mm distance from the mould wall.

Distance from the mould bottom: Direct spruing between wax units and mould bottom a distance of 10 – 15 mm has to be kept. Investment of running bars or rings: the middle of the running bar or ring should cover the middle of the mould.

4. Investment

Cover investment mould with investment ring spacer.

Investment mould x 1 / x 3: 1 layer

Investment mould x 6 / x 9: 1 – 2 layers

Phosphate bonded investment material is required.

The investment material manufacturer's instructions for use have to be complied with strictly.

5. Burnout / Preheating

Conventional heating: the first preheating step at approx. 280 °C has to be hold according to the mould size for respectively 30/40/50/60 min.; further heating steps in compliance with the investment material manufacturer's instruction for use. After reaching the final temperature (see data sheet), the holding time is according to the mould size respectively 20/30/45/60 min. If handling a greater number of moulds, the preheating time has to be extended accordingly.

Speed heating: the instructions of the manufacturer of the investment material have to be complied with strictly.

6. Crucible Material

Ceramic crucibles can be used.

7. Casting Units

All common melting and casting units can be used.

8. Casting

Check data sheet for casting temperatures.

Further heating times after reaching the liquidus temperature according to the quantity of material used and unit output.

Resistance heating 60 – 120 sec.

High frequency 5 – 10 sec.

Propane / Oxygen torch 5 – 10 sec.

In the case of torch melting, pay attention to the correct setting of the torch (danger of carbon damage) and melt with the reduced zone.

9. Casting Residues

In order to preserve the alloy characteristics and the casting quality, no more than 50 % cleaned casting residues should be used.

The weight used is calculated from: wax weight x alloy density (see Heimerle + Meule calculation sheet).

10. Cooling and Divestment

Let mould cool down to hand temperature and carefully divest. This avoids deviations in fitting, change of alloy characteristics, and hot fissures. Sandblast with high grade corundum (approx. 100 µm) or with an market pickling agent to remove the investment material.

11. Finishing and Cleaning

Finish frame with tungsten carbide burs and ceramic bonded milling tools with only little pressure; then sandblast surface with aluminium oxide (approx. 100 µm) at low pressure (max.2 bar). For frame parts which will not be veneered high gloss polishing is recommended. Then steamclean the frame and degrease it with a suitable pickling agent (e.g. AMISUL). During grinding sufficient protection against dust inhalation has to be taken.

12. Oxidation

Ensure sufficient support of the frame. 5 min. at 930 °C without vacuum.

If the oxide layer shows spots, grind the frame again and repeat the work steps (see point 11). For conditioning of the surface, sandblast the frame with aluminum oxide (approx. 100 µm, max. pressure 2 bar) again and pickle it with AMISUL. Thoroughly steamclean the object thereafter.

13. Firing of the Ceramic

Conventional ceramics, max. firing temperature 950 °C particularly ceramics with reduced firing temperatures are suitable for veneering. Veneering should be performed in compliance with the manufacturer's recommendations. Ideally suited for veneering is INSPIRATION or other marketable normal expanding ceramics.

During firing, a sufficient support of the frame has to be ensured; with larger span bridges an individual firing support made of phosphate bonded soldering investment material (e.g. DUROCONT L) is to be used

14. Firing Process

In regard to the firing process the indications of the respective ceramic manufacturer have to be complied with strictly.

15. Soldering

Soldering areas have to be sufficiently big and should already be considered during modelling.

Soldering areas have to be metallically blank.

The solder gap should be 0.05 – 0.2 mm.

Recommended soldering

investment material: DUROCONT L

Recommended flux material: Universal soldering paste ARGOFLEX

Solder before firing: PLATINOR® AM-Lot 1070 °C

Solders after firing: PLATINOR® Lot 1 810 °C

PLATINOR® Lot 2 760 °C

Slowly cool down the soldering object.

16. Hardening

After casting / firing the alloy shows a sufficiently high density for its area of indication. If required, the maximum hardening after veneering can be reached through final tempering in accordance to the data sheet.

17. Pickling and Polishing

Remove flux residues or oxides by pickling in AMISUL at about 80 °C or by sandblasting. Rubber-wheel the frame; final polishing can be accomplished with pastes, brushes, buffing wheels, and felt.